



30x30 STANDARD HIP END - FRAME TENT



30x30 Standard Frame Tent			
Qty	FITTINGS		Part #
4	Corner		C1001
4	Side Tee Joint		C1003
1	8 Way Crown		C1007
48	Canopy Pins		P102
Qty	Size	Poles	Color
8	14'-4"	Spreader	Red
4	21'-10"	Hip Rafter	Red
4	16'-1"	Rafter	Green
8	7'-8"	Legs	Black

INSTRUCTION:

1. Lay out four (4) corner fittings, four (4) tee fittings, one (1) 8-way top joint, eight (8) (red 14'4") spreader tubes, four (4) (green 16'1") rafter tubes, and four (4) (red 21'10") hip rafter tubes.
2. Start assembling from the peak: insert all rafter and hip rafter tubes into the 8-way top joint, and pin them.
3. Connect all corners to the 21'10" hip rafters first, and pin them.
4. Connect one of the corner legs to the tee fitting using 14'4" spreader tubes, then continue to connect from this tee to the opposite corner fittings, and pin them. Do this for all perimeter tubes.
5. Connect all 16'1" rafters to the tee joints.
6. Place the canopy over the frame and pull it tight. Secure the canopy to the frame with buckle straps. Tighten corner buckles first.
7. Raise one side of the canopy high enough to insert the leg tubes (black 7'8") into the corner fittings and pin.
8. Repeat step 7 for the opposite side of the canopy.
9. Insert all the remaining legs into the tee fittings and pin.
10. The canopy and frame can now be tied down.

Caution: Tie down only at the corner or tee fittings. Do not tie to the spreader tubes, as they may bend.