

10x40

1. Layout four (4) corner fittings, eight (8)(white 9'4"),and (4) (4'4") spreader pipe and form perimeter frame. Assemble nails or pins.
2. Assemble three (3) (white 9'4") spreader pipe into two (2) top tee fittings, and two (2) 6 ways crown fittings into center of frame.
3. On one end, insert one (1) yellow (6'10") hip rafter into corner fitting and nail. Then insert opposite end of hip rafter into 6 ways crown fitting and nail. Insert one end of another hip rafter into same 6way fitting and nail.
4. On the same end, insert one (1) (red 4'11") rafter pipe into the same 6way fitting and nail. Do the same for the opposing side.
5. Repeat step 3 and 4 for the other end.
6. Insert one end of center spreader into the assembled 3way crown fitting and nail.
7. Insert one end of side rafter (red4'11") into side tee fitting and nail. Do the same for opposite. Repeat for all rafter.
8. Place canopy over frame and pull tight . Secure canopy to frame with buckles straps, tightening corner buckle first.
9. Raise one side of canopy, insert leg pipes (black 7'8") into the corner and tee fittings and nail.
10. Raise opposite side of the canopy and install remaining legs.
11. The canopy and frame can now be tied down. Caution tie down only at corner or tee fittings. Do not tie to spreader pipe as they may bend.