



Quality Frame Tents for Rental and Commercial Industries

**CALL US: 800-997-8368**

EMAIL: [sales@centraltent.com](mailto:sales@centraltent.com)

Georgia Location: 889 Industrial Blvd Ringgold, GA 30736

Texas Location: 5911 Hamblen Dr, Humble, TX 77396, United States

**10x10 STANDARD HIP END - FRAME TENT**



10x10 Standard Frame Tent			
Qty	FITTINGS		Part #
4	Corner		C1001
1	4 Way Crown		C1005
24	Canopy Pins		P102
Qty	Size	Poles	Color
4	9'-4"	Spreader	White
4	6'-10"	Hip Rafter	Yellow
4	7'-8"	Legs	Black

**INSTRUCTION :**

1. Layout four (4) corner fittings and four (4) (white 9'4") spreader pipes and form a perimeter frame. Assemble and insert a 16p nail.
2. Put one (1) 4-way crown fitting in the center of the frame with arms facing corners. Insert one (1) (yellow 6'10") hip rafter pipe in the corner fitting and insert a 16p nail. Then insert the opposite end of the hip rafter into a 4-way crown fitting and nail.
3. Insert the three (3) remaining hip rafters into the 4-way crown fitting and insert 16p nails.

4. Place the canopy over a frame and pull tight. Secure canopy to frame with buckle straps. Tighten corner buckles first.
5. Raise one side of the canopy high enough to insert the leg pipes (black 7'8") into the corner fittings and 16p nail
6. Raise the opposite side of the canopy and install the remaining legs.
7. The canopy and frame can now be tied down. Caution, tie down only at corner fittings. Do not tie to the spreader pipe as they may bend.