



10x10 STANDARD HIP END - FRAME TENT



10x10 Standard Frame Tent			
Qty	FITTINGS		Part #
4	Corner		C1001
1	4 Way Crown		C1005
24	Canopy Pins		P102
Qty	Size	Poles	Color
4	9'-4"	Spreader	White
4	6'-10"	Hip Rafter	Yellow
4	7'-8"	Legs	Black

INSTRUCTION :

1. Layout four (4) corner fittings and four (4) (white 9'4") spreader pipes to form a perimeter frame. Assemble and insert pins.
2. Put one (1) 4-way crown fitting in the center of the frame with arms facing corners. Insert one (1) (yellow 6'10") hip rafter pipe into the corner fitting and insert a pin. Then insert the opposite end of the hip rafter into a 4-way crown fitting and pin.
3. Insert the three (3) remaining hip rafters into the 4-way crown fitting and insert a pin.
4. Place the canopy over the frame and pull tight. Secure the canopy to the frame with buckle straps. Tighten corner buckles first.
5. Raise one side of the canopy high enough to insert the leg pipes (black 7'8") into the corner fittings and pin.
6. Raise the opposite side of the canopy and install the remaining legs.
7. The canopy and frame can now be tied down.

Caution: Tie down only at corner or tee fittings. Do not tie to the spreader pipe, as they may bend.