



POP - UP TENT

INSTRUCTION :

- 1) Put the top on a frame before expanding
- 2) Velcro corners in place.
- 3) Pull and turn the round safety pins to unlock the legs. (horizontal is unlocked)
- 4). Expand the frame by two diagonal corners until upright.
- 5) Roll up top from each corner and pull and turn top pins into the vertically locked position.
- 6) Place your foot on the base plate to hold steady and raise each corner until pins lock in place.
- 7) Pull top-down from each corner using the corner webbing.
- 8) Make sure all top pins are secure.
- 9) Move to each leg, pull and turn pins to unlocked position (horizontal)
- 10) Raise each leg to the desired height and turn the bottom pins into the locked vertical position.



*****Top will be tight on the frame but will loosen and be easier in time**