

SET UP INSTRUCTIONS 30X40

1. Lay out four (4) corner fittings, six (6) side tee fittings, two (2) 6 way top joint, eight (8) (white 14'4") spreader pole, two (2) (white 9'4") spreader pole, one (1) (white 9'4") in the center, four (4) (red 21'10") hip rafter diagonally. Work on half frame first, start by inserting the six way top joint to the hip rafters and then connect the hip rafters to corner fittings. Pin all the poles to the fittings.
2. Connect the 2 corners with 9'4" white poles to 3 side tee joint, bring three (3) (green 16'1") rafter poles, start by inserting these 3 rafters to the 6 way top joint, pin it and connect it to the side tee joint, pin it.
3. Do the same on the other half frame .
4. Connect the two half frame with three (white) 9'4" poles.
5. Install the 2 tilted cables that connect 6 way top joint to the side tee on its sides.
6. Place vinyl cover on top of this frame, match the corner and pull tight. Secure it to the frame with buckle side straps, tighten corner buckles first.
8. Raise (preferably with canopy jack) 40' side high enough to insert the leg pipes (black 7'8") over the corner fittings and pin it.
9. Repeat step 8 for the opposite side of frame.
10. Insert all remaining legs over tee fittings and insert pins.
11. The vinyl cover and frame can now be tied down.
Caution : Tie down only at the corner or side tee fittings. Make sure the tie down cannot move side to side
Do not tie down to spreader pipe as they may bend.