

- 1) Put top on frame before expanding
- 2) Velcro corners in place
- 3) Pull and turn the round safety pins to unlock legs. (horizontal is unlocked)
- 4) Expand frame by two diagonal corners until upright
- 5) Roll up top from each corner and pull and turn top pins into vertical locked position
- 6) Place your foot on base plate to hold steady and raise each corner until pins lock in place
- 7) Pull top down from each corner using the corner webbing
- 8) Make sure all top pins are secure
- 9) Move to each leg, pull and turn pins to unlocked position (horizontal)
- 10) Raise each leg to desired height and turn bottom pins into locked vertical position

**\*\*top will be tight on frame but will loosen and be easier in time**

1) Put top on frame before expand

5) Roll up top from each corner

8) Make sure all top pins are secure